

Vector numbering system

	Position:	1	2	3	4	5*	-	A	B ¹	C*																																	
	Order No.:																																										
1st position	Continuous current rating: 9= 900 A continuous current 19= 1,200 A continuous current																																										
2nd position	Insulator: 6= 2 1/4" D.B.C. polymer insulators (only available with 25 kV) 7= 2 1/4" D.B.C. porcelain insulators (only available with 25 kV) 8= 3" D.B.C. polymer insulators 9= 3" D.B.C. porcelain insulators (only available with 38 kV)																																										
3rd position	Voltage class: 3= 25 kV, 150 kV BIL 4= 38 kV, 200 kV BIL																																										
4th position	Mounting style: Q= Symmetrical pole-top style X= Horizontal crossarm style P= Phase-over-phase style V= Vertical (cable riser style) U= Underslung (inverted style)																																										
5th position	Base style (No letter indicates galvanized steel switch base; proceed to position A*): F= Fiberglass switch base																																										
Options available after dash																																											
Position A	Operating method: 3= 28' of operating pipe (4@7") 4= 35' of operating pipe (5@7") 5= 49' of operating pipe (7@7") H= Hookstick-operated gang switch (HOG) ¹																																										
Position B ¹	Operating shaft insulator: 0= No operating shaft insulator 1= Porcelain operating shaft insulator 5= Polymer operating shaft insulator																																										
Position C	Optional accessories (multiple accessories can be selected and should be placed in alphabetical order*): If arrester is desired, choose one; if not, move to next selection: A= Lightning arrester mounting bracket (GALV) A2= Extended lightning arrester mounting bracket (GALV) A4= Extended lightning arrester mounting bracket (FIG) Choose as many as desired: B= Pole band C= Convertible to motorized E= Extended base length F= Fiberglass operating pipe section (not compatible with HOG) K= Six (6) cable connectors (wire size range #6-397.5 MCM ACSR, #4-500 MCM copper) L= Three (3) 16" extension links M= Marine grade R= Crossarm brace W= Wildlife design (60+° phase spacing) If interrupter is desired, choose one: N= Non-load break S= Plug-in Saf-T-Gap interrupters – 900 A T= Bolt-on Saf-T-Gap interrupters – 900 A																																										
Vector configuration examples: <table border="1"> <tbody> <tr> <td>Example A:</td> <td>9</td> <td>6</td> <td>3</td> <td>Q</td> <td>F</td> <td>-</td> <td>H</td> <td>M</td> <td></td> <td></td> </tr> <tr> <td>Example B:</td> <td>19</td> <td>9</td> <td>4</td> <td>U</td> <td></td> <td>-</td> <td>5</td> <td>1</td> <td>E</td> <td>L</td> </tr> <tr> <td>Example C:</td> <td>9</td> <td>8</td> <td>3</td> <td>X</td> <td></td> <td>-</td> <td>4</td> <td>5</td> <td>A</td> <td>B</td> </tr> </tbody> </table>											Example A:	9	6	3	Q	F	-	H	M			Example B:	19	9	4	U		-	5	1	E	L	Example C:	9	8	3	X		-	4	5	A	B
Example A:	9	6	3	Q	F	-	H	M																																			
Example B:	19	9	4	U		-	5	1	E	L																																	
Example C:	9	8	3	X		-	4	5	A	B																																	

¹ If hookstick operation is selected, position B does not apply; proceed to position C.

Consult factory for custom configurations.